



NOTES:

1. THIS METHOD OF WIRING PERMITS THE REMOVAL OF EQUIPMENT WITHOUT INTERRUPTING THE INTEGRITY OF THE CIRCUIT.
2. A SIMILAR CONNECTION MUST ALSO BE MADE FOR ALL CONDUCTORS BEING TAPPED.